







































































Original		Rechange		Original		Rechange	
	Power		Power		9		9
	PRO/TV/TXT		Text		0		0
	Goto/Cancel		3D		FAV		Pre Ch
	REP/Reveal		Options		Recall		Back
	Input		AV		Vol+		Vol +
	<</Hold		<<		Vol-		Vol -
	>>/Size		>>		CH+		Ch +
	I<</Subpage		I<<		CH-		Ch -
	>>I/Index		>>I		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Menu		Menu
	6		6		Exit		Exit
	7		7		EPG		Guide
	8		8		Info		Info



