



















































































































Original		Rechange		Original		Rechange	
	Power		Power		9		9
	Mute		Mute		0		0
	Picture	 + 	Shift + Format		FAV		Pre Ch
	Sound		Dual		Vol+		Vol +
	Input		AV		Vol-		Vol -
	Menu		Menu		Recall		Back
	Exit		Exit		CH+		Ch +
	16:9/4:3		Format		CH-		Ch -
	Info		Info		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Subtitle		Subt
	6		6		Audio	 + 	Shift + Dual
	7		7		Goto		Smart
	8		8		Repeat	 + 	Shift + Text





Original	Recharge
 CH List	 List
 Playlist	 Shift + Play
 EPG	 Guide
 Play	 Play
 ECO/TFT Off	 3D
 Pause/TS	 Pause
 Record	 Rec
 Stop	 Stop
 <<	 <<
 >>	 >>
 I<<	 I<<
 >>I	 >>I
 TV/TXT	 Text
 Hold	 Options
 Subpage	 TV/R
 Size	 Eject
 Red	 Red

Original	Recharge
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Sleep	 Sleep

