







































































Original		Rechange		Original		Rechange	
	Power		Power		P+		Ch +
	1		1		P-		Ch -
	2		2		Guide		Guide
	3		3		Menu		Menu
	4		4		i		Info
	5		5		Back		Back
	6		6		Exit		Exit
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	Lang		Dual		OK		Ok
	TXT		Text		Netflix		Media
	Vol+		Vol +		F Play		TV/R
	Vol-		Vol -		You Tube		Smart
	Mute		Mute		Prime Video		Options
	Source		AV		Red		Red





Original	Recharge	Original	Recharge
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 <<<	 <<<		
 Pause	 Pause		
 >>>	 >>>		
 Rec	 Rec		
 Play	 Play		
 Stop	 Stop		

