























































Original	Rechange	Original	Rechange
POWER		Power	
SOURCE		AV	
EXIT		Exit	
MENU		Menu	
MUTE		Mute	
Q. MENU		Options	
TEXT		Text	
OK		Ok	
UP		Up	
DOWN		Down	
RIGHT		Right	
LEFT		Left	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
EPG		Guide	
FOLDER		List	
V+		Vol +	
V-		Vol -	
P+		Ch +	
P-		Ch -	
SLEEP		Sleep	
BACK		Back	
PRESETS		D. Menu	
SUB / LANG.		Format	
RED / ZOOM		Red	
GREEN /		Green	



REPEAT

Original	Recharge	Original	Recharge
YELLOW / ROOT	 Yellow	> < / SIZE	 3D
BLUE / TITLE	 +  Shift + Blue	INTERNET	 +  Shift + Smart
SKIP PREV.	 I<<	RECALL	 Pre Ch
SKIP NEXT	 >>I	i	 Info
STOP	 Stop	NETFLIX	 Smart
PAUSE	 Pause		
REC	 Rec		
REW	 <<		
PLAY	 Play		
BLUE	 Blue		
	 +  Shift + Menu		
FAV/SEARCH/1	 +  Shift + 1		
FAV/DISC/2	 +  Shift + 2		
YOUTUBE	 Media		
TV	 TV/R		
SUBTITLE	 Subt		
MULTIMEDIA	 +  Shift + Media		

