





	Original	Recharge		Original	Recharge
	SRC	 AV	AV	 AF RPT	AF/RPT
	BND Disc Up	 SMART	Smart	 REPEAT TEXT	Text
	Volume+	 + VOL	Vol +	 SEARCH TVR	TV/R
	Volume-	 VOL -	Vol -		
	Mute	 MUTE	Mute		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	Search >>I		>>I		
	I<< Search		I<<		
	Play/Pause	 OK	Ok		
	Play	 PLAY MODE	Play		
	Pause		Pause		
	TA	 SETTINGS OPT	Options		
	Disp	 DISPLAY INFO	Info		
	PS/AS/SCN	 APP MEDIA	Media		

