

































































































Original		Recharge		Original		Recharge	
	Power		Power		Exit/TV-G		Exit
	1		1		?		Smart
	2		2		@		Media
	3		3		Menu/i		Menu
	4		4		Back		Back
	5		5		Tools		Options
	6		6		Guide		Guide
	7		7		OK		Ok
	8		8		Up		Up
	9		9		Down		Down
	0		0		Right		Right
	FAV/ZAPP		Pre Ch		Left		Left
	TXT		Text		Vol+		Vol +
	Red		Red		Vol-		Vol -
	Green		Green		PR+		Ch +
	Yellow		Yellow		PR-		Ch -
	Blue		Blue		AV		AV





Original		Rechange		Original		Rechange	
	Mute		Mute				
	I<		I<<				
	>I		>>I				
	<<		<<				
	>>		>>				
	Rec		Rec				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	3D/Search		Format				
	..O/Audio		Dual				
	[...].		Subt				
	PIP/ECO		3D				
	My Media/CEC		TV/R				

