










































































Original	Recharge
 Mute	 Mute / Dimmer
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Swap	 Setup / OPT /
 0	 0
 AV	 AV / Input / RDS
 []	 Shift + 1
 ♪	 Sound / Title
 [<>]	 Picture / Format

Original	Recharge
 [i]	 Info / Angle
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Vol+	 Vol+
 Text	 Text / Goto
 Menu	 Menu / Home
 CH+	 CH+ / Page+
 Vol-	 Vol-
 Back	 Back / Return
 Tv/Exit	 TV/ Radio /





Original		Rechange	
	CH-		CH- / Page-
	FAV		Fav / Marker / PC
	Subtitle		Subtitle / EQ
	Audio		Audio / Lang I/II
	Guide		Guide / EPG / -/--
	[?]		Shift + Info / Angle
	[≡x]		Shift + 5
	[:≡]		Shift + 4
	[⇅]		Shift + 3
	[⇅]		Shift + 2
	PIP Pos		D.Menu / Top
	PIP Size		Zoom / Size
	PIP		Eject / Surround

Original		Rechange	

