



	Original	Rechange	Original	Rechange
	POWER	 Power		 <<
	PLAY/PAUSE	 Pause	 PLAY/PAUSE	 Play
	INPUT	 AV		 >>
	^	 Up		
	ENTER	 Ok		
	v	 Down		
	<	 Left		
	>	 Right		
	VOL +	 Vol +		
	VOL -	 Vol -		
	MUTE	 Mute		
	DISPLAY	 Info		
	REPEAT	 Text		
	SUBTITLE	 Subt		
	ZOOM	 Eject		
	RESET	 Back		
	STOP	 Stop		

