





































































































Original		Rechange		Original		Rechange	
	Power		Power		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		Vol+		Vol +
	5		5		Vol-		Vol -
	6		6		P+		Ch +
	7		7		P-		Ch -
	8		8		Mute		Mute
	9		9		i		Info
	0		0		Exit		Exit
	↔		Pre Ch		Source		AV
	Back		Back		Q.Menu		D. Menu
	Menu		Menu		EPG		Guide
	Netflix		Media		TXT		Text
	Internet		Smart		*		Format
	Ok		Ok		*/Q		3D





Original		Rechange		Original		Rechange	
	[>]		Options				
	Lang		Dual				
	Subt.		Subt				
	[+]		Shift + Format				
	TV		TV/R				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Rec		Rec				
	Play		Play				
	Stop		Stop				
	Pause		Pause				
	<<		<<				
	>>		>>				

