



Original	Rechange
Power	Power
Sleep	Sleep
Mute	Mute
Timer	AV
EPI	Guide
SUBTL	Subt
Audio	Shift + Dual
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0

Original	Rechange
16:9	Format
Lang	Dual
RCL	Back
FAV	Pre Ch
Page+ / Timeshift	Shift + Ch +
Page- / V-Format	Shift + Ch -
Page- / V-Format	Shift + Format
Up / CH+	Up
Up / CH+	Ch +
Down / CH-	Down
Down / CH-	Ch -
Right / Vol+	Right
Right / Vol+	Vol +
Left / Vol-	Left
Left / Vol-	Vol -
OK	Ok
Menu	Menu





Original	Recharge	Original	Recharge
 Info	 Info	 Slow	 Shift + Play
 TXT	 Text	 Rec	 Rec
 Exit	 Exit	 Media	 Media
 Red / SAT	 Red	 Game	 Smart
 Green / Zoom	 Green	 PVR	 Shift + Smart
 Green / Zoom	 Eject	 HDD	 Shift + Media
 Yellow / Pause	 Yellow		
 Yellow / Pause	 Shift + Pause		
 Blue / TV/Radio	 Blue		
 Blue / TV/Radio	 TV/R		
 <<	 <<		
 >>	 >>		
 Play / Pause	 Play		
 Play / Pause	 Pause		
 Stop	 Stop		
 I<<	 I<<		
 >>I	 >>I		

Original	Recharge
 Slow	 Shift + Play
 Rec	 Rec
 Media	 Media
 Game	 Smart
 PVR	 Shift + Smart
 HDD	 Shift + Media

