



| Original | Recharge |
|---|--|
|  Power |  Power |
|  Input |  AV / Input / RDS |
|  Netflix |  Shift + Red / Netflix / |
|  Youtube |  Shift + Yellow / YouTube / |
|  Subtitles |  Subtitle / EQ |
|  Stop |  Stop / Hold |
|  Mute |  Mute / Dimmer |
|  << |  << / Tune- |
|  Play / Pause |  Play / Slow |
|  Play / Pause |  Pause / Step / Freeze |
|  >> |  >> / Tune+ |
|  Text |  Text / Goto |
|  Guide |  Guide / EPG / -/-- |
|  Aspect |  Picture / Format |
|  Up |  Up |
|  Left |  Left |
|  OK |  OK |

| Original | Recharge |
|--|---|
|  Right |  Right |
|  Down |  Down |
|  Back |  Back / Return |
|  Home |  Menu / Home |
|  Home |  Shift + Menu / |
|  Options |  Shift + Setup / OPT / Tools |
|  Options |  Setup / OPT / |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  Google Assist |  Smart / List |
|  CH+ |  CH+ / Page+ |
|  CH- |  CH- / Page- |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |





| Original | | Rechange | | Original | | Rechange | |
|----------|--------|----------|-----------------------------|----------|--|----------|--|
| | 6 | | 6 | | | | |
| | 7 | | 7 | | | | |
| | 8 | | 8 | | | | |
| | 9 | | 9 | | | | |
| | 0 | | 0 | | | | |
| | Info | | Info / Angle | | | | |
| | Recall | | Fav / Marker / PC | | | | |
| | Red | | Red / Netflix / Search | | | | |
| | Green | | Green / APP / Repeat | | | | |
| | Yellow | | Yellow / YouTube / Repeat | | | | |
| | Blue | | Blue / Prime Video / Random | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

