

























































	Original	Rechange		Original	Rechange
	Power		Power		7
	Mute		Mute		8
	OK		Ok		9
	Up		Up		0
	Down		Down		Menu
	Left		Left		Exit
	Right		Right		EPG
	CH+		Ch +		Subtitle
	CH-		Ch -		Audio
	Vol-		Vol -		FAV
	Vol+		Vol +		Recall
	1		1		Text
	2		2		Info
	3		3		Pause
	4		4		Yellow
	5		5		Red
	6		6		Green





Original		Rechange		Original		Rechange	
	Blue		Blue				
	Tv/Radio		TV/R				

