































































Original	Rechange
 Piloto	 Smart / List
 Guia	 Guide / EPG / -/--
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Prefe	 Fav / Marker / PC
 0	 0
 →/Salir	 Exit / Cancel / Clear
 Serv	 Menu / Home
 +	 CH+ / Page+
 Perso	 Display / Media

Original	Rechange
 Left	 Left
 Up	 Up
 Right	 Right
 OK	 OK
 Down	 Down
 A	 Red / Netflix / Search
 B	 Green / APP / Repeat
 C	 Yellow / YouTube / Repeat
 D	 Blue / Prime Video / Random
 E	 Zoom / Size
 Mute	 Mute / Dimmer
 TV/SAT	 TV/Radio /
 Power	 Power

