



Original	Rechange
Standby	Power
Teletex	TEXT
Red	Red (A)
Green/[ ] Smart	Green (B)
Yellow/Smart	Yellow (C)
Blue	Blue (D)
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Clear	EXIT

Original	Rechange
Timer	-/-- / EPG
Menu	MENU
Mute	MUTE
P<P	P/C / FAV
OK	OK
Up	UP
Down	DOWN
Right	RIGHT
Left	LEFT
P+	CH +
P-	CH -
Vol+	VOL +
Vol-	VOL -
Play	Play
Stop	Stop
Record/OTR	Rec
<<	Rewind



