






















































	Original	Rechange	Original	Rechange
	Power			Right
	Time			Down
	Display			I<< Prev
	Open / Close			>>I Next
	Angle			<< FR
	Language			>> FF
	Sub.Title			Zoom
	Title			Setup
	Menu / PBC			L / R
	P / N			Repeat
	Return			Mark
	Mute			Goto
	Play			Pause / Step
	Stop			Slow
	Up			1
	Left			2
	Enter			3




Original
Rechange

	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Vol+		Vol +
	Vol-		Vol -

Original
Rechange

