































































































Original	Recharge	Original	Recharge
 Power	 Power	 Audio In	 Shift + Dual
 Still	 Pause	 CH Return	 Pre Ch
 Wide	 Format	 CH+	 Ch +
 TV	 TV/R	 CH-	 Ch -
 Video	 AV	 Vol+	 Vol +
 RGB	 Eject	 Vol-	 Vol -
 Teletext	 Text	 Menu	 Menu
 1	 1	 Mute	 Mute
 2	 2	 Dual/Stereo	 Dual
 3	 3	 Up	 Up
 4	 4	 Right	 Right
 5	 5	 Down	 Down
 6	 6	 Left	 Left
 7	 7	 Enter	 Ok
 8	 8	 Red	 Red
 9	 9	 Green	 Green
 0	 0	 Yellow	 Yellow





Original		Rechange		Original		Rechange	
	Blue		Blue				
	Subpage		Subt				
	Reveal		Options				
	Size		3D				
	Hold		Smart				
	Index		Guide				
	Mode		Back				
	Cancel		Exit				
	Store		Rec				
	Display		Info				
	Picture Mode		>>				
	Picture Memory		>>				
	Off-Timer		Sleep				

