


































































































| Original      | Rechange  | Original   | Rechange  |
|---------------|---|------------|---|
| PWR On/Off    |  Power                 | Radio      |  TV/Radio /              |
| Mute          |  Mute / Dimmer         | Sys/Serv   |  D.Menu / Top            |
| H/V Play      |  Play / Slow           | Scan/Setup |  Setup / OPT /           |
| Dec/Pause     |  Pause / Step / Freeze | Text       |  Text / Goto             |
| East          |  Stop / Hold           | P.lock     |  AV / Input / RDS        |
| Lang./Rewind  |  Rec / Rec Mode        | Menu       |  Menu / Home             |
| LNB F.Forward |  << / Tune-            | Menu Up    |  Up                      |
| Interat       |  >> / Tune+            | Info       |  Info / Angle            |
| +             |  I<< / Preset-         | Menu Left  |  Left                    |
| De-emph       |  >>I / Preset+        | OK Enter   |  OK                     |
| 50j17         |  Sound / Title       | Menu Right |  Right                 |
| Subt.List     |  Audio / Lang I/II   | Exit       |  Exit / Cancel / Clear |
| Navi Mode     |  Subtitle / EQ       | Menu Down  |  Down                  |
| Alt/16:9      |  Eject / Surround    | Swap       |  Back / Return         |
| Wn            |  Picture / Format    | Volume+    |  Vol+                  |
| Sleep Timer   |  Zoom / Size         | TV         |  Smart / List          |
|               |  Sleep / Timer       | CH/Page+   |  CH+ / Page+           |



| Original     | Recharge   | Original     | Recharge  |
|--------------|--|--------------|---|
| Volume-      |  Vol-                     | Yellow       |  Yellow / YouTube / Repeat       |
| Display      |  Display / Media          | Blue         |  Blue / Prime Video / Random     |
| CH/Page-     |  CH- / Page-              | On/Off       |  Shift + Power                   |
| 1. ?         |  1                        | Freeze       |  Shift + Pause / Step /          |
| 2abc         |  2                        |              |  Shift + Stop /                  |
| 3def         |  3                        | Tune-        |  Shift + << /                    |
| 4ghi         |  4                        | Tune+        |  Shift + >> /                    |
| 5jkl         |  5                        | Aft/Caf      |  Shift + D.Menu / Top Menu       |
| 6mno         |  6                        | Auth./DISEQC |  Shift + Menu /                  |
| 7pqrm        |  7                       | Help         |  Shift + Info / Angle           |
| 8tuv         |  8                      | View         |  Shift + OK                    |
| 9wxyz        |  9                      | Clear        |  Shift + Exit / Cancel / Clear |
| Guide Pilote |  Guide / EPG / -/--     | Copy/Delete  |  Shift + Smart / List          |
| 0/10         |  0                      | CHH+         |  Shift + CH+ /                 |
| FAV Pref.    |  Fav / Marker / PC      | Erase        |  Shift + Display / Media       |
| Red          |  Red / Netflix / Search | CHH-         |  Shift + CH- /                 |
| Green        |  Green / APP / Repeat   | Video        |  Shift + 4                     |

| Original     | Recharge  | Original     | Recharge  |
|--------------|---|--------------|---|
| Yellow       |  Yellow / YouTube / Repeat       | Blue         |  Blue / Prime Video / Random     |
| On/Off       |  Shift + Power                   | Freeze       |  Shift + Pause / Step /          |
| Freeze       |  Shift + Pause / Step /          |              |  Shift + Stop /                  |
| Tune-        |  Shift + << /                    | Tune+        |  Shift + >> /                    |
| Tune+        |  Shift + >> /                    | Aft/Caf      |  Shift + D.Menu / Top Menu       |
| Aft/Caf      |  Shift + D.Menu / Top Menu       | Auth./DISEQC |  Shift + Menu /                  |
| Auth./DISEQC |  Shift + Menu /                  | Help         |  Shift + Info / Angle           |
| Help         |  Shift + Info / Angle           | View         |  Shift + OK                    |
| View         |  Shift + OK                    | Clear        |  Shift + Exit / Cancel / Clear |
| Clear        |  Shift + Exit / Cancel / Clear | Copy/Delete  |  Shift + Smart / List          |
| Copy/Delete  |  Shift + Smart / List          | CHH+         |  Shift + CH+ /                 |
| CHH+         |  Shift + CH+ /                 | Erase        |  Shift + Display / Media       |
| Erase        |  Shift + Display / Media       | CHH-         |  Shift + CH- /                 |
| CHH-         |  Shift + CH- /                 | Video        |  Shift + 4                     |
| Video        |  Shift + 4                     |              |   |



