



Original		Rechange		Original		Rechange	
	Red / -1		Red		Contrast+		Right
	Green / +1		Green		Stop Video		Stop
	Yellow / Stop		Yellow		7		7
	Blue / [= ?]		Blue		<< Video		<<
	[=] / [TV]		Text		8		8
	1		1		>> Video		>>
	l<< Video		l<<		9		9
	2		2		*-		Down
	>>l Video		>>l		Pause Video		Pause
	3		3		*+		Up
	Tint-		Media		Play Video		Play
	Tint+		Smart		0 / AV		0
	4		4		Up / P+		Ch +
	5		5		i		Info
	6		6		P / C		Back
	Contrast-		Left		Left / Vol-		Vol -
	Rec Video		Rec		OK		Ok





Original	Recharge	Original	Recharge
Right / Vol+	Vol +		
Mute	Mute		
Down / P-	Ch -		
Power	Power		

