



| Original  | Rechange  | Original  | Rechange  |
|---|---|---|---|
|  Power             |  Power                 |  Menu            |  Menu / Home           |
|  Mute              |  Mute / Dimmer         |  Up              |  Up                    |
|  Play              |  Play / Slow           |  i               |  Info / Angle          |
|  Pause             |  Pause / Step / Freeze |  Left            |  Left                  |
|  Stop              |  Stop / Hold           |  OK              |  OK                    |
|  Rec               |  Rec / Rec Mode        |  Right           |  Right                 |
|  <<                |  << / Tune-            |  Exit            |  Exit / Cancel / Clear |
|  >>                |  >> / Tune+            |  Down            |  Down                  |
|  Lang              |  Audio / Lang I/II     |  Back            |  Back / Return         |
|  Source (Games)    |  Eject / Surround      |  Vol+            |  Vol+                  |
|  Movie-Music-Phot |  Picture / Format     |  World (Violet) |  Smart / List         |
|  [≡]..           |  Zoom / Size         |  PR+           |  CH+ / Page+         |
|  */O             |  Sleep / Timer       |  Vol-          |  Vol-                |
|  TV              |  TV/Radio /          |  */Q           |  Display / Media     |
|  Q.Menu          |  D.Menu / Top        |  PR-           |  CH- / Page-         |
|  [-O-]           |  Setup / OPT /       |  1             |  1                   |
|  [≡]/Text        |  Text / Goto         |  2             |  2                   |





|  | Original | Recharge                    | Original | Recharge |
|--|----------|-----------------------------|----------|----------|
|  | 3        | 3                           |          |          |
|  | 4        | 4                           |          |          |
|  | 5        | 5                           |          |          |
|  | 6        | 6                           |          |          |
|  | 7        | 7                           |          |          |
|  | 8        | 8                           |          |          |
|  | 9        | 9                           |          |          |
|  | Guide    | Guide / EPG / -/--          |          |          |
|  | 0        | 0                           |          |          |
|  | Red      | Red / Netflix / Search      |          |          |
|  | Green    | Green / APP / Repeat        |          |          |
|  | Yellow   | Yellow / YouTube / Repeat   |          |          |
|  | Blue     | Blue / Prime Video / Random |          |          |
|  | Recall   | Shift + Back / Return       |          |          |
|  |          |                             |          |          |
|  |          |                             |          |          |
|  |          |                             |          |          |
|  |          |                             |          |          |

