







































































Original		Rechange		Original		Rechange	
	Power		Power		Rec		Rec / Rec Mode
	Source		AV / Input / RDS		<<		<< / Tune-
	1		1		Stop		Stop / Hold
	2		2		Play		Play / Slow
	3		3		Pause		Pause / Step / Freeze
	4		4		>>		>> / Tune+
	5		5		Vol+		Vol+
	6		6		P+		CH+ / Page+
	7		7		Mute		Mute / Dimmer
	8		8		Vol-		Vol-
	9		9		P-		CH- / Page-
	0		Shift + Guide / EPG / -/--		Menu		Menu / Home
	PRE-CH		0		Exit		Exit / Cancel / Clear
	Fav / Marker / PC		Fav / Marker / PC		Up		Up
	TV/Radio /		TV/Radio /		Left		Left
	Smart / List		Smart / List		Enter/OK		OK
	D.Menu / Top		D.Menu / Top		Right		Right





Original		Recharge		Original	Recharge
	Down		Down		
	Return		Back / Return		
	Info		Info / Angle		
	Anynet		Display / Media		
	Red		Red / Netflix / Search		
	Green		Green / APP / Repeat		
	Yellow		Yellow / YouTube / Repeat		
	Blue		Blue / Prime Video / Random		
	Text/Mix		Text / Goto		
	[≡◆]/P.Size		Zoom / Size		
	[≡o]/P.Mode		Picture / Format		
	[≡+]/PIP		Setup / OPT /		
	Guide		Guide / EPG / -/--		
	I-II/Dual		Audio / Lang I/II		
	Still		Eject / Surround		
	Subtitle		Subtitle / EQ		

