














































	Original	Recharge		Original	Recharge
	Power		Power		-/--
	Power2		Shift + Power		←•→ +
	Mute		Mute		←•→ -
	PP		Back		Contrast+
	[]		Format		Contrast-
	Input		AV		Brightness+
	[*]		Info		Brightness-
	1		1		Color+
	2		2		Color-
	3		3		Vol+
	4		4		Vol-
	5		5		
	6		6		
	7		7		
	8		8		
	9		9		
	0		0		

