



Original	Recharge
 Power	 Power
 Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 EPG	 Guide
 Info	 Info
 Red	 Red
 Green	 Green
 Yellow	 Yellow

Original	Recharge
 Blue	 Blue
 Opciones	 Menu
 [++]	 Options
 Back	 Back
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Home	 Smart
 CH.List	 List
 Mute	 Mute
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -





Original	Recharge
Pause	Pause
Play	Play
Stop	Stop
<<	<<
>>	>>
PVR	TV/R
Netflix	Media
YouTube	Shift + Media
Subtitle	Subt
TTX	Text

Original	Recharge

