



Original		Rechange		Original		Rechange	
	Power		Power		Info		Info
	Input		AV		Vol+		Vol +
	Sport		TV/R		Vol-		Vol -
	P.Mode		Format		Mute		Mute
	S.Mode		Shift + Dual		CH.List		List
	Sleep		Sleep		Home		Smart
	1		1		CH+		Ch +
	2		2		CH-		Ch -
	3		3		*		Menu
	4		4		[≡]		Options
	5		5		Back		Back
	6		6		Exit		Exit
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	Guide		Guide		OK		Ok



