






























































































Original		Rechange		Original		Rechange	
	Power		Power		Blue		Blue / Prime Video / Random
	Input		AV / Input / RDS		[=]		TV/Radio /
	1		1		TXT		Text / Goto
	2		2		Subtitle		Subtitle / EQ
	3		3		Back		Back / Return
	4		4		Up		Up
	5		5		Down		Down
	6		6		Left		Left
	7		7		Right		Right
	8		8		OK		OK
	9		9		Home		Menu / Home
	0		0		Micro		Display / Media
	Guide		Guide / EPG / -/--		Vol+		Vol+
	Info		Info / Angle		Vol-		Vol-
	Red		Red / Netflix / Search		Mute		Mute / Dimmer
	Yellow		Yellow / YouTube / Repeat		CH+		CH+ / Page+
	Green		Green / APP / Repeat		CH-		CH- / Page-





Original	Recharge
	 << / Tune-
	 Play / Slow
	 >> / Tune+
	 Pause / Step / Freeze
	 Smart / List
	 Stop / Hold
	 +  Shift + Red / Netflix /
	 +  Shift + Yellow / YouTube /
	 +  Shift + Blue / Prime
	 D.Menu / Top

Original	Recharge

