







































































Original	Rechange	Original	Rechange
	Power		Power
	Netflix		Media
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TV		TV/R
	↔		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	P+		Ch +
	P-		Ch -
	Internet		Smart
	Menu		Menu
	Q.Menu		D. Menu
	Back		Back
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	i		Info
	EPG		Guide
	[>]		List
	* / o		Format





Original	Rechange	Original	Rechange
*/Q	3D		
TXT	Text		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		
Lang	Dual		
Subt.	Subt		
←[+]→	Eject		
<<	<<		
>>	>>		
Pause	Pause		
Rec	Rec		
Play	Play		
Stop	Stop		

