







































































Original		Recharge		Original		Recharge	
	On		Power		Digital		Pre Ch
	Standby		Shift + Power		Page Up		Ch +
	ID 1		Red		Page Down		Ch -
	ID 2		Green		Magnify On		Smart
	ID 3		Yellow		Magnify Off		Media
	ID 4		Blue		Vol+		Vol +
	Computer 1		1		Vol-		Vol -
	Computer 2		2		AV Mute		Mute
	Computer 3		3		Freeze		Pause
	LAN		4		F5		Text
	USB Type A		5		Reset		AV
	USB Type B		6		Menu		Menu
	Component		7		Up		Up
	S.Video		8		Down		Down
	Video		9		Right		Right
	HDMI 1		Guide		Left		Left
	HDMI 2		0		Enter		Ok









































































Original		Rechange		Original		Rechange	
ESC	ESC	CLEAR EXIT	Exit				
PbyP	PbyP	PICTURE FORMAT	Format				
ASPECT	Aspect	ECO 3D	3D				
AUTO	Auto	SEARCH TV/R	TV/R				
1	My Button 1	SHIFT + 1	Shift + 1				
2	My Button 2	SHIFT + 2	Shift + 2				
3	My Button 3	SHIFT + 3	Shift + 3				
4	My Button 4	SHIFT + 4	Shift + 4				
POSITION	Position	SETTINGS OPT	Options				
LENS SHIFT	Lens Shift	DISPLAY INFO	Info				
KEYSTONE	Keystone	SOUND DUAL	Dual				
LENS MEMORY	Lens Memory	RETURN BACK	Back				
+ FOCUS	Focus +	>>	>>				
- FOCUS	Focus -	<<	<<				
+ ZOOM	Zoom +	>>	>>				
- ZOOM	Zoom -	<<	<<				





Original		Recharge		Original		Recharge	
	On		Power		Digital		Pre Ch
	Standby		Shift + Power		Page Up		Ch +
	ID 1		Red		Page Down		Ch -
	ID 2		Green		Magnify On		Smart
	ID 3		Yellow		Magnify Off		Media
	ID 4		Blue		Vol+		Vol +
	Computer 1		1		Vol-		Vol -
	Computer 2		2		AV Mute		Mute
	Computer 3		3		Freeze		Pause
	LAN		4		F5		Text
	USB Type A		5		Reset		AV
	USB Type B		6		Menu		Menu
	Component		7		Up		Up
	S.Video		8		Down		Down
	Video		9		Right		Right
	HDMI 1		Guide		Left		Left
	HDMI 2		0		Enter		Ok









































































Original		Rechange	
	ESC		Exit
	PbyP		Format
	Aspect		3D
	Auto		TV/R
	My Button 1		Shift + 1
	My Button 2		Shift + 2
	My Button 3		Shift + 3
	My Button 4		Shift + 4
	Position		Options
	Lens Shift		Info
	Keystone		Dual
	Lens Memory		Back
	Focus +		>>
	Focus -		<<
	Zoom +		>>I
	Zoom -		I<<

Original		Rechange	





Original		Recharge		Original		Recharge	
	On		Power		Digital		Pre Ch
	Standby		Shift + Power		Page Up		Ch +
	ID 1		Red		Page Down		Ch -
	ID 2		Green		Magnify On		Smart
	ID 3		Yellow		Magnify Off		Media
	ID 4		Blue		Vol+		Vol +
	Computer 1		1		Vol-		Vol -
	Computer 2		2		AV Mute		Mute
	Computer 3		3		Freeze		Pause
	LAN		4		F5		Text
	USB Type A		5		Reset		AV
	USB Type B		6		Menu		Menu
	Component		7		Up		Up
	S.Video		8		Down		Down
	Video		9		Right		Right
	HDMI 1		Guide		Left		Left
	HDMI 2		0		Enter		Ok









































































Original		Rechange	
	ESC		Exit
	PbyP		Format
	Aspect		3D
	Auto		TV/R
	My Button 1		Shift + 1
	My Button 2		Shift + 2
	My Button 3		Shift + 3
	My Button 4		Shift + 4
	Position		Options
	Lens Shift		Info
	Keystone		Dual
	Lens Memory		Back
	Focus +		>>
	Focus -		<<
	Zoom +		>>I
	Zoom -		I<<

Original		Rechange	





Original		Recharge		Original		Recharge	
	On		Power		Digital		Pre Ch
	Standby		Shift + Power		Page Up		Ch +
	ID 1		Red		Page Down		Ch -
	ID 2		Green		Magnify On		Smart
	ID 3		Yellow		Magnify Off		Media
	ID 4		Blue		Vol+		Vol +
	Computer 1		1		Vol-		Vol -
	Computer 2		2		AV Mute		Mute
	Computer 3		3		Freeze		Pause
	LAN		4		F5		Text
	USB Type A		5		Reset		AV
	USB Type B		6		Menu		Menu
	Component		7		Up		Up
	S.Video		8		Down		Down
	Video		9		Right		Right
	HDMI 1		Guide		Left		Left
	HDMI 2		0		Enter		Ok





Original	Rechange
 ESC	 Exit
 PbyP	 Format
 Aspect	 3D
 Auto	 TV/R
 My Button 1	 Shift + 1
 My Button 2	 Shift + 2
 My Button 3	 Shift + 3
 My Button 4	 Shift + 4
 Position	 Options
 Lens Shift	 Info
 Keystone	 Dual
 Lens Memory	 Back
 Focus +	 >>
 Focus -	 <<
 Zoom +	 >>I
 Zoom -	 I<<

Original	Rechange

