























































Original	Rechange	Original	Rechange
 Power	 Power	 My Button 1	 1
 Video	 Red	 My Button 2	 2
 Computer/Storage	 Green	 Keystone	 Options
 Search	 TV/R	 Position	 3D
 Aspect	 Format	 Menu	 Menu
 Auto	 List	 Up	 Up
 Blank	 Info	 Left	 Left
 Magnify On	 >>	 Enter	 Ok
 Magnify Off	 <<	 Right	 Right
 Home	 Smart	 Down	 Down
 End	 Media	 Esc	 Exit
 Page Up	 Ch +	 Reset	 Back
 Page Down	 Ch -		
 Volume	 Vol -		
 Volume	 Vol +		
 Mute	 Mute		
 Freeze	 Pause		

