



































Original	Recharge
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Text	 Text / Goto
 0	 0
 Recall	 Back / Return
 Imagen	 Picture / Format
 Sonido	 Sound / Title
 Audio	 Audio / Lang I/II

Original	Recharge
 Sleep	 Sleep / Timer
 Fuente	 Shift + Subtitle / EQ
 P+	 CH+ / Page+
 Vol+	 Vol+
 Info	 Info / Angle
 P-	 CH- / Page-
 Vol-	 Vol-
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Menu	 Menu / Home
 Down	 Down



