













| Original | | Recharge | | Original | | Recharge | |
|---|-------------------|---|-------------------------------|---|---------------|---|-----------------------------|
|  | Power |  | Power |  | Index / Goto |  | Shift + Text / |
|  | I<< |  | I<< / Preset- |  | Red/Program |  | Red / Netflix / Search |
|  | Eject |  | Eject / Surround |  | Red/Program |  | TV/Radio / |
|  | << |  | << / Tune- |  | Green/Slow |  | Green / APP / Repeat |
|  | >> |  | >> / Tune+ |  | Green/Slow |  | Shift + Play / |
|  | >> |  | >> / Preset+ |  | Yellow/Repeat |  | Yellow / YouTube / Repeat |
|  | Play/Pause |  | Play / Slow |  | Yellow/Repeat |  | Shift + Green / APP / |
|  | TV/TXT / |  | Text / Goto |  | Blue/A-B |  | Blue / Prime Video / Random |
|  | TV/TXT / |  | Audio / Lang I/II |  | Blue/A-B |  | Shift + Yellow / YouTube / |
|  | Cancel / Zoom |  | Shift + Exit / Cancel / Clear |  | CH+ |  | CH+ / Page+ |
|  | Cancel / Zoom |  | Shift + Zoom / |  | TV Menu |  | Menu / Home |
|  | Reveal / Subtitle |  | Shift + Subtitle / EQ |  | Vol+ |  | Vol+ |
|  | Stop |  | Stop / Hold |  | CH- |  | CH- / Page- |
|  | Hold / Menu |  | D.Menu / Top |  | Source |  | AV / Input / RDS |
|  | Hold / Menu |  | Shift + Stop / |  | Vol- |  | Vol- |
|  | Size / Angle |  | Shift + Info / Angle |  | DTV |  | Shift + 1 |
|  | Subpage / Title |  | Shift + Sound / Title |  | DVD Setup |  | Setup / OPT / |





| Original | | Rechange | | Original | | Rechange | |
|----------|---------|----------|----------------------------|----------|-------------|----------|---------------------------|
| | Up | | Up | | 0 | | 0 |
| | Left | | Left | | Recall | | Back / Return |
| | OK | | OK | | Picture | | Picture / Format |
| | Right | | Right | | Sound | | Sound / Title |
| | Down | | Down | | I/II | | Shift + Audio / Lang I/II |
| | Exit | | Exit / Cancel / Clear | | Mute | | Mute / Dimmer |
| | Display | | Display / Media | | Sleep | | Sleep / Timer |
| | 1 | | 1 | | Info | | Info / Angle |
| | 2 | | 2 | | Zoom | | Zoom / Size |
| | 3 | | 3 | | Freeze | | Pause / Step / Freeze |
| | 4 | | 4 | | EPG | | Guide / EPG / -/-- |
| | 5 | | 5 | | FAV List | | Smart / List |
| | 6 | | 6 | | FAV ADD | | Fav / Marker / PC |
| | 7 | | 7 | | FAV >>I | | Shift + Right |
| | 8 | | 8 | | Subtitle | | Subtitle / EQ |
| | 9 | | 9 | | Time | | Shift + Sleep / Timer |
| | -/-- | | Shift + Guide / EPG / -/-- | | Quick Start | | Shift + Smart / List |

