



Original	Rechange
Power	Power
Sleep	Sleep
Mute	Mute
Timer	AV
EPI	Guide
SUBTL	Subt
Audio	Shift + Dual
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0

Original	Rechange
16:9	Format
Lang	Dual
RCL	Back
FAV	Pre Ch
Page+ / Timeshift	Shift + Ch +
Page- / V-Format	Shift + Ch -
Page- / V-Format	Shift + Format
Up / CH+	Up
Up / CH+	Ch +
Down / CH-	Down
Down / CH-	Ch -
Right / Vol+	Right
Right / Vol+	Vol +
Left / Vol-	Left
Left / Vol-	Vol -
OK	Ok
Menu	Menu





Original		Recharge	
	Info		Info
	TXT		Text
	Exit		Exit
	Red / SAT		Red
	Green / Zoom		Green
	Green / Zoom		Eject
	Yellow / Pause		Yellow
	Yellow / Pause		Shift + Pause
	Blue / TV/Radio		Blue
	Blue / TV/Radio		TV/R
	<<		<<
	>>		>>
	Play / Pause		Play
	Play / Pause		Pause
	Stop		Stop
	<<		<<
	>>		>>

Original		Recharge	
	Slow		Shift + Play
	Rec		Rec
	Media		Media
	Game		Smart
	PVR		Shift + Smart
	HDD		Shift + Media

