















| Original | Rechange |
|--|---|
|  Power |  Power |
|  Sleep |  Sleep / Timer |
|  Mute |  Mute / Dimmer |
|  Mode |  AV / Input / RDS |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  Eject/Nicam2 |  Eject / Surround |
|  Eject/Nicam2 |  Sound / Title |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  TXT/MIX |  Text / Goto |
|  Play/Pause |  Play / Slow |
|  Play/Pause |  Pause / Step / Freeze |
|  7 |  7 |
|  8 |  8 |

| Original | Rechange |
|--|---|
|  9 |  9 |
|  Stop/Exit/Cancel |  Exit / Cancel / Clear |
|  Stop/Exit/Cancel |  Stop / Hold |
|  -/-- |  Guide / EPG / -/-- |
|  0 |  0 |
|  Back |  Back / Return |
|  SYS Menu |  Menu / Home |
|  Rec |  Rec / Rec Mode |
|  Up |  Up |
|  CH+ |  CH+ / Page+ |
|  DTV/Radio |  TV/Radio / |
|  Left |  Left |
|  Enter |  OK |
|  Right |  Right |
|  Vol- |  Vol- |
|  Down |  Down |
|  CH- |  CH- / Page- |





| Original | Recharge |
|---------------|----------------------------|
| Vol+ | Vol+ |
| Return | Shift + Back / Return |
| Menu DVD | D.Menu / Top |
| Setup | Setup / OPT / |
| Display | Display / Media |
| Search/FAV | Shift + Red / Netflix / |
| Search/FAV | Fav / Marker / PC |
| Slow/EPG | Shift + Play / |
| Slow/EPG | Shift + Guide / EPG / -- |
| Language/Info | Audio / Lang I/II |
| Language/Info | Info / Angle |
| Zoom/List | Zoom / Size |
| Zoom/List | Smart / List |
| Red/Angle | Red / Netflix / Search |
| Red/Angle | Shift + Info / Angle |
| Green/Program | Green / APP / Repeat |
| Green/Program | Shift + TV/Radio / Program |

| Original | Recharge |
|---------------|-----------------------------|
| Yellow/Repeat | Shift + Green / APP / |
| Yellow/Repeat | Yellow / YouTube / Repeat |
| Blue/A-B | Blue / Prime Video / Random |
| Blue/A-B | Shift + Yellow / YouTube / |
| <</Hold | Shift + Stop / |
| <</Hold | << / Tune- |
| >>/Index | >> / Tune+ |
| I<</Size | I<< / Preset- |
| I<</Size | Shift + Zoom / |
| >>I/Reveal | >>I / Preset+ |
| Subtitle | Subtitle / EQ |
| Title/Subpage | Shift + Sound / Title |
| FAV- | Shift + Down |
| FAV+ | Shift + Up |

