























































Original	Rechange
 Power	 Power
 Sleep	 Sleep
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Back	 Back
 Null	 Shift + Eject
 Vol+	 Vol +
 Vol-	 Vol -

Original	Rechange
 Aspect	 3D
 Audio	 Dual
 Display	 Info
 CH+	 Ch +
 CH-	 Ch -
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK/Enter	 Ok
 Input	 AV
 PMode	 Shift + Format
 Ch.List	 List
 SMode	 Shift + Dual
 FAV	 Pre Ch





Original		Rechange		Original		Rechange	
	EPG		Guide		>>I		>>I
	TV/Radio		TV/R		I<<<		I<<<
	Subtitle		Subt		Red		Red
	Text		Text		Green		Green
	Index		Smart		Yellow/ (A)		Yellow
	Mix		Eject		Blue		Blue
	Hold		Media				
	Reveal		Options				
	Subpage		Shift + Subt				
	Cancel		D. Menu				
	Size		Format				
	Rec		Rec				
	Stop		Stop				
	Play		Play				
	T-Shift/Pause		Pause				
	<<		<<				
	>>		>>				

