







































































	Original	Rechange	Original	Rechange			
	Standby		Power		Search		TV/R
	Menu		Menu		Stop		Stop
	Title		Options		Pause		Pause
	Setup		Sleep		Repeat		Text
	Up		Up		Zoom		Shift + Eject
	Down		Down		Slow		Eject
	Right		Right		A-B		Shift + Play
	Left		Left		Vol+		Vol +
	>>		>>		Vol-		Vol -
	<<		<<		1		1
	>>		>>		2		2
	<<		<<		3		3
	Subtitle		Subt		4		4
	Angle		Guide		5		5
	Audio		Dual		6		6
	Play		Play		7		7
	Display		Info		8		8





	Original	Recharge	Original	Recharge
	9	9		
	0	0		

