







































	Original	Rechange
	Power	 Power
	Feedback	 Dual
	Bluetooth	 Smart
	Connect	 Media
	Soundshift	 Subt
	Vol+	 Vol +
	Vol-	 Vol -
	Mute	 Mute
	Bass+	 Ch +
	Bass-	 Ch -
	HDMI 1	 1
	HDMI 2	 2
	HDMI 3	 3
	HDMI TV	 TV/R
	AUX	 AV
	Optical	 Options
	Harman Volume	 Guide

	Original	Rechange
	Virtual Surround	 Pre Ch

