



| Original                                                                                            | Rechange                                                                                                | Original                                                                                            | Rechange                                                                                                  |
|-----------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
|  Power             |  Power                 |  Menu            |  Menu / Home           |
|  Mute              |  Mute / Dimmer         |  Up              |  Up                    |
|  Play              |  Play / Slow           |  i               |  Info / Angle          |
|  Pause             |  Pause / Step / Freeze |  Left            |  Left                  |
|  Stop              |  Stop / Hold           |  OK              |  OK                    |
|  Rec               |  Rec / Rec Mode        |  Right           |  Right                 |
|  <<                |  << / Tune-            |  Exit            |  Exit / Cancel / Clear |
|  >>                |  >> / Tune+            |  Down            |  Down                  |
|  Lang              |  Audio / Lang I/II     |  Back            |  Back / Return         |
|  Source (Games)    |  Eject / Surround      |  Vol+            |  Vol+                  |
|  Movie-Music-Phot |  Picture / Format     |  World (Violet) |  Smart / List         |
|  [≡]..           |  Zoom / Size         |  PR+           |  CH+ / Page+         |
|  */O             |  Sleep / Timer       |  Vol-          |  Vol-                |
|  TV              |  TV/Radio /          |  */Q           |  Display / Media     |
|  Q.Menu          |  D.Menu / Top        |  PR-           |  CH- / Page-         |
|  [-O-]           |  Setup / OPT /       |  1             |  1                   |
|  [≡]/Text        |  Text / Goto         |  2             |  2                   |





| Original                                                                            |        | Recharge                                                                            |                             |
|-------------------------------------------------------------------------------------|--------|-------------------------------------------------------------------------------------|-----------------------------|
|    | 3      |    | 3                           |
|    | 4      |    | 4                           |
|    | 5      |    | 5                           |
|    | 6      |    | 6                           |
|    | 7      |    | 7                           |
|    | 8      |    | 8                           |
|    | 9      |    | 9                           |
|    | Guide  |    | Guide / EPG / -/--          |
|    | 0      |    | 0                           |
|   | Red    |   | Red / Netflix / Search      |
|  | Green  |  | Green / APP / Repeat        |
|  | Yellow |  | Yellow / YouTube / Repeat   |
|  | Blue   |  | Blue / Prime Video / Random |
|  | Recall |  | Shift + Back / Return       |
|                                                                                     |        |                                                                                     |                             |
|                                                                                     |        |                                                                                     |                             |
|                                                                                     |        |                                                                                     |                             |
|                                                                                     |        |                                                                                     |                             |

| Original |  | Recharge |  |
|----------|--|----------|--|
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |
|          |  |          |  |

