








































































Original	Rechange
 MUTE	 Mute
 POWER	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TEXT	 Text
 HOLD	 +  Shift + Stop
 SUBPAGE	 Subt
 FAV	 Pre Ch
 AUDIO	 Dual

Original	Rechange
 MENU	 Menu
 UP	 Up
 INPUT	 AV
 LEFT	 Left
 OK	 Ok
 RIGHT	 Right
 BACK	 Back
 DOWN	 Down
 EXIT	 Exit
 VOL+	 Vol +
 SLEEP	 Sleep
 CH+	 Ch +
 VOL-	 Vol -
 CH-	 Ch -
 RED	 Red
 GREEN	 Green
 YELLOW	 Yellow



