



Original	Rechange
Power	Power
Repeat	Text
A-B	Shift + Text
Open / Close	Eject
N / P	TV/R
Subtitle	Subt
Angle	Format
Language	Dual
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9

Original	Rechange
0	0
10+	Guide
Time	AV
Setup	Options
Title	Media
Up	Up
Right	Right
Down	Down
Left	Left
Enter	Ok
PBC	Smart
Menu	Menu
Vol -	Vol -
Vol +	Vol +
Zoom	Shift + Eject
Return	Back
L / R	Shift + Dual





	Original	Recharge	
	Step	 + 	Shift + Pause
	Slow	 + 	Shift + Play
	Clear		Exit
	Program		Sleep
	Mute		Mute
	Display		Info
	Prev I<<		I<<
	Next >>I		>>I
	Rev <<		<<
	Fwd >>		>>
	Stop		Stop
	Play / Pause		Play
	Play / Pause		Pause
	V-Mode		3D

	Original	Recharge

