



































































































Original	Rechange	Original	Rechange
 Power	 Power	 *	 Menu
 1	 1	 Back	 Back
 2	 2	 Guide	 Guide
 3	 3	 Home/Recents	 Info
 4	 4	 Netflix	 Shift + Media
 5	 5	 Amazon	 Media
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0/Quick Access	 0	 OK	 Ok
 List	 List	 Wheel Up	 >>
 Vol+	 Vol +	 Wheel Down	 <<
 Vol-	 Vol -	 Source	 AV
 P+	 Ch +	 Text	 Text
 P-	 Ch -	 T.Opt/Magic Link	 Options
Mute	Mute	Red	Red

Original	Rechange	Original	Rechange
 *	 Menu	 Back	 Back
 Guide	 Guide	 Home/Recents	 Info
 Netflix	 Shift + Media	 Amazon	 Media
 Up	 Up	 Down	 Down
 Right	 Right	 Left	 Left
 OK	 Ok	 Wheel Up	 >>
 Wheel Down	 <<	 Source	 AV
 Text	 Text	 T.Opt/Magic Link	 Options
Red	Red		



