







































































Original		Rechange		Original		Rechange	
	Power		Power		Input		AV / Input / RDS
	1		1		Tv/Rad		TV/Radio /
	2		2		AV Mode		Shift + AV / Input / RDS
	3		3		Energy/Saving		Eject / Surround
	4		4		Portal		Display / Media
	5		5		Vol+		Vol+
	6		6		Vol-		Vol-
	7		7		P+		CH+ / Page+
	8		8		P-		CH- / Page-
	9		9		Info		Info / Angle
	0		0		Exit		Exit / Cancel / Clear
	Q.View		Sound / Title		Back		Back / Return
	Home		Menu / Home		OK		OK
	Q.Menu		D.Menu / Top		Up		Up
	Guide		Guide / EPG / -/--		Down		Down
	List		Smart / List		Right		Right
	Mute		Mute / Dimmer		Left		Left





Original	Recharge	Original	Recharge
 Red	 Red / Netflix / Search		
 Green	 Green / APP / Repeat		
 Yellow	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		
 Text	 Text / Goto		
 Subtitle	 Subtitle / EQ		
 AD	 Audio / Lang I/II		
 Play	 Play / Slow		
 T.Opt	 Setup / OPT /		
 Alarm	 Sleep / Timer		
 Stop	 Stop / Hold		
 Pause	 Pause / Step / Freeze		
 Simplink	 Zoom / Size		
 <<	 << / Tune-		
 >>	 >> / Tune+		
 Ratio	 Picture / Format		
 Mark	 Fav / Marker / PC		

