







































































	Original	Rechange	Original	Rechange
	 Power	 Power	 List	 List
	 TV/PC	 Smart	 Q.view	 Media
	 Input	 AV	 Menu	 Menu
	 Tv/Radio	 TV/R	 Exit	 Exit
	 Text	 Text	 Info	 Info
	 I/II	 Dual	 Guide	 Guide
	 Mute	 Mute	 Up	 Up
	 1	 1	 Down	 Down
	 2	 2	 Right	 Right
	 3	 3	 Left	 Left
	 4	 4	 OK	 Ok
	 5	 5	 Vol+	 Vol +
	 6	 6	 Vol-	 Vol -
	 7	 7	 PR+	 Ch +
	 8	 8	 PR-	 Ch -
	 9	 9	 Return	 Back
	 0	 0	 Lighting	 3D





Original		Recharge		Original	Recharge
	Q.Menu		D. Menu		
	FAV		Pre Ch		
	T.Opt		Options		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	Stop		Stop		
	Play		Play		
	Pause		Pause		
	<<		<<		
	>>		>>		
	Subtitle		Subt		
	Mark		Format		

