





































Original	Rechange
 Power	 Power
 D/A Tv	 Smart
 Input	 AV
 Guide	 Guide
 Radio	 TV/R
 Subtitle/*	 Subt
 PIP PR-	 Shift + Ch +
 PIP PR+	 Shift + Ch -
 Swap	 Media
 PIP Input	 Shift + AV
 PIP	 Shift + 3D
 Info	 Info
 Back	 Back
 ARC	 3D
 Menu	 Menu
 Text	 Text
 Exit	 Exit

Original	Rechange
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 FAV	 Pre Ch
 CH+	 Ch +
 CH-	 Ch -
 1	 1
 2	 2





















































Original		Rechange		Original		Rechange	
	3		3		Sleep		Sleep
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	List		List				
	Q.View		D. Menu				
	[≡♦]/Size		Format				
	[≡X]/Position		Eject				
	[≡i]/Scan/Index		Shift + Info				
	[≡o]/Time		Shift + Text				
	[≡?]/Reveal		Options				
	[≡+]/Hold		Shift + Subt				
	I/II		Dual				












































Original	Recharge
 Power	 Power
 Menu	 Menu
 Up	 Up
 OK	 Ok
 Down	 Down
 Right	 Right
 Left	 Left
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Recharge
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 <<	 <<
 >>	 >>
 <<	 <<
 >>	 >>





Original	Recharge	Original	Recharge
 Power	 Power	 Rec	 Rec
 Input	 AV	 <<<	 <<<
 CH+	 Ch +	 >>>	 >>>
 CH-	 Ch -		
 1	 1		
 2	 2		
 3	 3		
 4	 4		
 5	 5		
 6	 6		
 7	 7		
 8	 8		
 9	 9		
 0	 0		
 Play	 Play		
 Pause	 Pause		
 Stop	 Stop		

