




Original		Rechange		Original		Rechange	
	Power		Power		AV Input Tv		AV
	Bluetooth		Dual		Mute Tv		Shift + Mute
	Vol+		Vol +		PR/CH+ Tv		Shift + Ch +
	Vol-		Vol -		PR/CH- Tv		Shift + Ch -
	Woofer Level+		Ch +		Vol+ Tv		Shift + Vol +
	Woofer Level-		Ch -		Vol- Tv		Shift + Vol -
	*		Eject				
	Optical		Smart				
	Mute		Mute				
	LG Tv		Subt				
	3D Sound On		List				
	3D Sound Off		Info				
	DRC On		Menu				
	DRC Off		Exit				
	Auto Power On		Sleep				
	Auto Power Off		TV/R				
	Power Tv		Shift + Power				

