




































































Original	Rechange
 Power	 Power
 Radio & Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Clear	 Exit
 Repeat	 Text
 Open/Close	 Eject
 Play	 Play
 Stop	 Stop

Original	Rechange
 Pause	 Pause
 Scan >>	 >>
 << Scan	 <<
 Skip >>	 >>
 I<< Skip	 I<<
 Rec	 Rec
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Info/Display	 Info
 Home	 Smart
 Back	 Back
 Disc Menu	 D. Menu
 Title/PopUp	 List
 Sound Effect	 Dual
 Optical	 Options
 Music ID	 Subt



