







































































Original		Rechange		Original		Rechange	
	Power		Power		Down		Down
	Mute		Mute / Dimmer		Exit		Exit / Cancel / Clear
	Picture		Picture / Format		1		1
	Sound		Sound / Title		2		2
	Aspect		Shift + Picture / Format		3		3
	Sleep		Sleep / Timer		4		4
	Subtitle		Subtitle / EQ		5		5
	CH. List		Smart / List		6		6
	EPG		Guide / EPG / -/--		7		7
	FAV		Fav / Marker / PC		8		8
	TV / Radio		TV/Radio /		9		9
	Up		Up		0		0
	Input		AV / Input / RDS		Recall		Back / Return
	Left		Left		Info		Info / Angle
	OK		OK		Vol +		Vol+
	Right		Right		Rec		Rec / Rec Mode
	Menu		Menu / Home		Rec. List		Display / Media





	Original	Rechange	Original	Rechange
		CH +		CH+ / Page+
		Vol -		Vol-
		Play / Pause		Play / Slow
		Play / Pause		Pause / Step / Freeze
		Stop		Stop / Hold
		CH -		CH- / Page-
		Red		Red / Netflix / Search
		Green		Green / APP / Repeat
		Yellow		Yellow / YouTube / Repeat
		Blue		Blue / Prime Video / Random
		TV / TXT		Text / Goto
		Cancel		Shift + Exit / Cancel / Clear
		Reveal		Eject / Surround
		Nicam / A2		Audio / Lang I/II
		<< / Index		<< / Tune-
		>> / Hold		>> / Tune+
		<< / Size		<< / Preset-

