










































































Original		Recharge		Original		Recharge	
	Power		Power		Down		Down
	1		1		Right		Right
	2		2		Left		Left
	3		3		OK		Ok
	4		4		P+		Ch +
	5		5		P-		Ch -
	6		6		<<		<<
	7		7		Vol+		Vol +
	8		8		Vol-		Vol -
	9		9		Mute		Mute
	0		0		Red		Red
	AV		AV		Green		Green
	Text		Text		Yellow		Yellow
	Menu		Menu		Blue		Blue
	End		Exit		EPG		Guide
	Info		Info		Plus		Smart
	Up		Up		Radio		TV/R





Original

Rechange

 #PIP	 ECO 3D	 3D

Original

Rechange