












































Original	Recharge	Original	Recharge
Power		Power	
Recall		Back / Return	
CC		Subtitle / EQ	
Text		Text / Goto	
Smart		Smart / List	
Sleep		Sleep / Timer	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
Reset		Exit / Cancel / Clear	

Original	Recharge	Original	Recharge
CH / Guide		Guide / EPG / -/--	
Up		Up	
M		Menu / Home	
A / CH		Info / Angle	
Down		Down	
Vol+		Vol+	
Vol-		Vol-	
Left / -		Left	
Right / +		Right	
Mute		Mute / Dimmer	
CH+		CH+ / Page+	
CH-		CH- / Page-	
A		Red / Netflix / Search	
B		Green / APP / Repeat	
C		Yellow / YouTube / Repeat	
D		Blue / Prime Video / Random	
G		Shift + Yellow / YouTube / Repeat	






































































Original	Recharge	
Clock	 + 	Shift + Sleep / Timer
E	 + 	Shift + Red / Netflix /
F	 + 	Shift + Green / APP /
A / V		AV / Input / RDS

Original	Recharge







































Original	Rechange	Original	Rechange
Power	 Power	Power	 Power
Recall	 Back / Return	Recall	 Back / Return
CC	 Subtitle / EQ	CC	 Subtitle / EQ
Text	 Text / Goto	Text	 Text / Goto
Smart	 Smart / List	Smart	 Smart / List
Sleep	 Sleep / Timer	Sleep	 Sleep / Timer
1	 1	1	 1
2	 2	2	 2
3	 3	3	 3
4	 4	4	 4
5	 5	5	 5
6	 6	6	 6
7	 7	7	 7
8	 8	8	 8
9	 9	9	 9
0	 0	0	 0
Reset	 Exit / Cancel / Clear	Reset	 Exit / Cancel / Clear

Original	Rechange	Original	Rechange
Up	 Up	Up	 Up
CH / Guide	 Guide / EPG / -/--	CH / Guide	 Guide / EPG / -/--
Down	 Down	Down	 Down
M	 Menu / Home	M	 Menu / Home
Vol+	 Vol+	Vol+	 Vol+
A / CH	 Info / Angle	A / CH	 Info / Angle
Vol-	 Vol-	Vol-	 Vol-
Mute	 Mute / Dimmer	Mute	 Mute / Dimmer
Left / -	 Left	Left / -	 Left
Right / +	 Right	Right / +	 Right
CH+	 CH+ / Page+	CH+	 CH+ / Page+
CH-	 CH- / Page-	CH-	 CH- / Page-
A	 Red / Netflix / Search	A	 Red / Netflix / Search
B	 Green / APP / Repeat	B	 Green / APP / Repeat
C	 Yellow / YouTube / Repeat	C	 Yellow / YouTube / Repeat
D	 Blue / Prime Video / Random	D	 Blue / Prime Video / Random
Clock	 Shift + Sleep / Timer	Clock	 Shift + Sleep / Timer






Original	Recharge	
Power		Power
Recall		Back / Return
CC		Subtitle / EQ
Text		Text / Goto
Smart		Smart / List
Sleep		Sleep / Timer
1		1
2		2
3		3
4		4
5		5
6		6
7		7
8		8
9		9
0		0
Reset		Exit / Cancel / Clear

Original	Recharge	
CH / Guide		Guide / EPG / -/--
Up		Up
Down		Down
A / CH		Info / Angle
M		Menu / Home
Right / +		Right
Left / -		Left
Vol+		Vol+
Vol-		Vol-
Mute		Mute / Dimmer
CH+		CH+ / Page+
CH-		CH- / Page-
A		Red / Netflix / Search
B		Green / APP / Repeat
C		Yellow / YouTube / Repeat
D		Blue / Prime Video / Random
E		Shift + Red / Netflix / Search





Original	Recharge	Original	Recharge
F	 +  REPEAT		Shift + Green / APP /
G	 +  REPEAT A-B		Shift + Yellow / YouTube /
Clock	 + 		Shift + Sleep / Timer
A / V			AV / Input / RDS

