





























| Original     | Recharge   | Original   | Recharge  |
|--------------|--|------------|---|
| On/Off       |  Power  | Display    |  Info      |
| Audio Off    |  Mute   | Menu Right |  Right     |
| Slow Down    |  Ch -   | Menu Down  |  Down      |
| Stop         |  Stop   | Progr.     |  Sleep     |
| Auto/Track   |  +  Shift + Subt | Return     |  Back      |
| Slow Up      |  Ch +   | Volume+    |  Vol +     |
| Subt.        |  Subt   | Volume-    |  Vol -     |
| Rep/A-B      |  +  Shift + Text | 1          |  1         |
| Pause        |  Pause  | 2          |  2         |
| Title        |  Smart  | 3          |  3         |
| DVD/TV       |  AV  | Next       |  >>       |
| Pepeat/1/All |  Text   | 4          |  4       |
| Zoom         |  Eject  | Prev.      |   <<     |
| Menu         |  Menu   | 5          |  5       |
| Menu Up      |  Up   | Setup      |  Options |
| Menu Left    |  Left   | Top Menu   |  D. Menu |
| OK Enter     |  Ok   | 6          |  6       |



| Original    | Recharge   | Original | Recharge   |
|-------------|--|----------|--|
| 7           |  7  | Resume   |  List   |
| 8           |  8  | 3D       |  3D     |
| Pbc         |  Media  | Angle    |  Format |
| R/L         |  +  Shift + Dual     |          |  |
| 9           |  9  |          |  |
| +10         |  Guide  |          |  |
| 0           |  0  |          |  |
| Np          |  +  Shift + Smart    |          |  |
| Clear/00:00 |  Exit   |          |  |
| C/CH        |  Pre Ch   |          |  |
| Play        |  Play  |          |  |
| Open/Close  |  +  Shift + Mute |          |  |
| Rewind      |  <<   |          |  |
| Record      |  Rec  |          |  |
| Audio       |  Dual   |          |  |
| F.Forward   |  >>   |          |  |
| Shuffle     |  TV/R   |          |  |

