






































| Original | Rechange |
|--|--|
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Mute |  Mute |
|  16:9 |  Format |
|  Red |  Red |
|  Green |  Green |
|  Yellow |  Yellow |
|  Blue |  Blue |

| Original | Rechange |
|---|---|
|  TV |  TV/R |
|  AV |  AV |
|  Up / P+ |  Up |
|  Up / P+ |  Ch + |
|  Down / P- |  Down |
|  Down / P- |  Ch - |
|  Right / V+ |  Right |
|  Right / V+ |  Vol + |
|  Left / V- |  Left |
|  Left / V- |  Vol - |
|  Menu |  Menu |
|  Menu |  Ok |
|  S / M / D |  Smart |
|  Recall |  Pre Ch |
|  Recall |  Back |
|  ≡ |  Text |
|  /≡ |  Options |





| Original | Recharge | Original | Recharge |
|----------|----------|----------|--------------|
| | ≡o | | Sleep |
| | ≡i | | Info |
| | Hold | | Pause |
| | Size | | Eject |
| | ≡X | | Exit |
| | ≡? | | D. Menu |
| | PP | | Media |
| | i | | Shift + Info |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

