







































| Original | | Rechange | | Original | | Rechange | |
|---|----------|---|--------|---|--------|---|--------|
|  | Standby |  | Power |  | Info |  | Info |
|  | DTV/VCR |  | Smart |  | Menu |  | Menu |
|  | Mute |  | Mute |  | EPG |  | Guide |
|  | 1 |  | 1 |  | Exit |  | Exit |
|  | 2 |  | 2 |  | CH+ |  | Ch + |
|  | 3 |  | 3 |  | CH- |  | Ch - |
|  | 4 |  | 4 |  | Up |  | Up |
|  | 5 |  | 5 |  | Down |  | Down |
|  | 6 |  | 6 |  | Right |  | Right |
|  | 7 |  | 7 |  | Left |  | Left |
|  | 8 |  | 8 |  | OK |  | Ok |
|  | 9 |  | 9 |  | Vol+ |  | Vol + |
|  | 0 |  | 0 |  | Vol- |  | Vol - |
|  | FAV |  | Pre Ch |  | Text |  | Text |
|  | Audio |  | Dual |  | Red |  | Red |
|  | Recall |  | Back |  | Green |  | Green |
|  | Subtitle |  | Subt |  | Yellow |  | Yellow |



