























Original		Recharge		Original		Recharge	
	Power		Power		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Netflix		Media
	6		6		Guide		Guide
	7		7		Source		AV
	8		8		P+		Ch +
	9		9		P-		Ch -
	0		0		Vol+		Vol +
	List		List		Vol-		Vol -
	Info		Info		Mute		Mute
	Home		Smart		<</Reveal		<<
	Menu		Menu		Play/Index		Play
	Back		Back		>>/Hold		>>
	Exit		Exit		Pause		Pause





Original	Recharge	Original	Recharge
 Stop	 Stop		
 Subtitle	 Subt		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Text	 Text		
 FAV	 Pre Ch		
 AD	 Shift + Subt		
 I/II	 Dual		

